




This section shows how to get to remove the Fuel Tank.












Disconnect two Vents. It is not needed to mark which one goes where. They can be swapped.



Remove Fuel Line Connector





Use a tea towel to protect tank before lifting off. The triple tree clamp is very close and very sharp.



Find a friend to help you lift the tank while you hunt for the fuel pump connector wires and disconnect them.

Find a friend to help you lift the tank while you hunt for the fuel pump connector wires and disconnect them.



Disconnect Fuel Pump Plug





Although this guide doesn't have a price tag it is copyrighted and formally registered. If you like what you see and this has helped you, please make a donation via **PAYPAL** to **richard@coote1.com**. Your support will help make more manuals like this available. If you haven't helped yet please donate so I can continue to offer these guides.

If there are any tools in this manual you would like to purchase, please email me at **richard@coote1.com** for prices and availability. We are slowly developing useful tools to help make it easier for you to work on your pride and joy.



**2013 Norton Commando SE #107 (left)    2014 Norton Commando SE#112 (right)**